

ORDNANCE SURVEY

PLAN SD 5236 & PLAN SD 5336

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.


Revised August 1965
Levelled 1961

Scale: 1:2500 or 25:344 inches to 1 mile

Revised August 1965
Levelled 1961

The West half of this sheet is Plan SD 5236
The East half of this sheet is Plan SD 5336

PLAN SD 5236 & PLAN SD 5336



Made and published by the Director General of the Ordnance Survey, Chessington, Surrey, 1966.
Reconstituted from former County Series plans 1960. Last revised 1965.

© Crown Copyright 1966.

The West half of this sheet is Plan SD 5236
The East half of this sheet is Plan SD 5336

PLAN SD 5236 & PLAN SD 5336

- Antiquities (site of)
- Change of boundary mering
- Limit of area within which the acreages of individual parcels are not shown
- Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.
Bench Mark lists, containing fuller and possibly later levelling information, are obtainable from the Director General, Ordnance Survey.
- Boundary Mering Abbreviations
- Base of Bank
- Centre of Bank
- Centre of Canal, etc
- Centre of Drain, etc
- Centre of Covered Stream
- Bench Mark
- Fundamental
- Parcels joined for acreages
- Levelling Information
- Centre of Old Course of Stream
- Centre of Road, etc
- Centre of Stream
- 4 feet from Root of Hedge
- Face of Fence
- Surface Level
- Revision Point or Traverse Station
- Triangulation Station
- Face of Wall
- Side of River, etc
- Track of Stream
- 4 feet from Root of Hedge
- Defaced, Undeined

REFERENCE

For fuller information see Reference Card published separately.

NATIONAL GRID REFERENCE

The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows:-

EXAMPLE: T in Tunsteds

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins. Estimate tens of metres from the grid line	Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins. Estimate tens of metres from the grid line
527	363
5273	3636

TEN METRE REFERENCE: SD 5273636

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".
The representation on this plan of a road, right or path is no evidence of the existence of a right of way.
A square inch on this plan represents 9/16 of an acre on the ground.
The allocation of tenets where shown is approximate.

- Boer House
- Bench Mark
- Boundary Post
- Boundary Stone
- Capstan
- Cane
- Drinking Fountain
- Electricity Pillar or Post
- Fire Alarm Pillar
- Flanstaff
- Foot Bridge
- Fundamental Bench Mark
- Mean High or Low Water
- Guide Post
- Letter Box, or Post
- Level Crossing
- Mail Pick-up
- Mile, or Mooring Post
- Mile Stone
- Pillar, Pole or Post
- Electricity Transmission Line
- Fire Alarm Pillar
- Flanstaff
- Foot Bridge
- Fundamental Bench Mark
- Mean High or Low Water
- Revision Point
- Signal Box, or Post
- Signal Bridge
- Spring
- Stone
- Sundial
- Tank or Trunk
- Telephone Call Box
- Traverse Station
- Water Point, or Tap
- Weightbridge
- Well
- Wind Pump
- Mean High or Low Water Springs

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

PLAN SD 5236 & PLAN SD 5336